

# ADING WATERPROOFING TAPE

*Waterproofing tape for securing critical joints, made by thermoplastic elastomer and polyester wrap knitted fleece*

## FIELD OF APPLICATION

For securing critical joints when waterproofing with Hidromal, Hidromal Fleks, Hidromal Fleks 1K, Adingfleks and other waterproofing based on synthetic resins. The tape is placed on working joints, cracks, smaller joints for installations, joints between vertical and horizontal planes in sanitary units and kitchens. It is placed on the first freshly applied layer of waterproofing.

## PROPERTIES

- The product is highly conformable;
- Remains flexible throughout its service life;
- Easy to use;
- Good chemical resistance;
- Tearing resistant;
- Water repellent;
- Vapor permeable;
- Temperature stability: - 30°C / + 90°C

## METHOD FOR CONSTRUCTION

### SUBSTRATE PREPARATION

The tape should be placed on a freshly applied layer of waterproofing, applied on a concrete, cement mortar or plasterboard. The surface should be clean, solid, without cracks, labile parts, existing coatings, grease and dust.

### APPLICATION

The application of the tape is manually by pressing directly onto the surface immediately after applying the first layer of waterproofing.



WATERPROOFING

## PACKING

The product is packed in rolls with protective paper, with dimensions 0.55 x 120 mm and lengths of 50m.

## STORAGE

In original, closed packaging, in dry and cold spaces  
Shelf life: 24 months.

**Health hazard:** The product is not classified as dangerous according to Article 31 and Annex 2 of the EU REACH regulation. If swallowed, seek medical attention.

**Protection:** During application of Adding waterproofing tape, protection of the respiratory system is not required. Also, protective equipment for skin and hands is not required. If the product is used frequently or for a long period of time, it is necessary to wear protective gloves. After application, it is mandatory to wash hands and avoid contact with eyes.

**Eye contact:** In case of product contact with eyes, wash eyes with water. Seek medical attention if prolonged irritation occurs. Wash immediately with plenty of water for 15 minutes. Remove your contact lenses and open your eyes wide. Seek medical attention if discomfort occurs.

**Skin contact:** Wipe off and wash with soap and water. Seek medical attention if irritation occurs.

**Inhalation:** Move to fresh air. Seek medical attention if the discomfort persists.

The information provided in this technical prospectus is obtained from laboratory tests and experiences. The properties given are typical and are not specified. In comparison to the wide range and variations of substrates, we recommend that the product be tested by the user to determine suitability for a specific application.